

Bliss Box Former




FIGURE 14-1
POWER HEAD
FEED ASSEMBLY

ITEM	PART NO.	DESCRIPTION	QTY.
1	0038202	SHAFT MOUNT	2
2	0038300	CRANK, MAIN SHAFT	2
3	0038400	PUSHER, OPERATING LEVER	2
4	0038500	LEVER, SHAFT OPERATING	2
5	0038601	PAWL, HEAD PUSHER	2
6	0038700	BLOCK, CON ROD PIVOT	2
7	0038801	SHAFT, END FEED	2
8	0038902	ROD, SHAFT CON	2
9	0100100	5/16 SET COLLAR	4
10	0201000	BUSHING	2
11	8030700	10-32 SKT HD CAP SCR X 1	6
12	1201400	SPRING	2
13	1201500	SPRING	2
14	8006800	1/4-20 HEX HD CAP SCR X 1/2	2
15	8025500	1/4-20 FIBER LOCK NUT	2
16	8007000	1/4-20 HEX HD CAP SCR X 1	2
17	8032700	1/4-20 SKT HD CAP SCR X 1	4
18	8028600	5/16-18 OVAL PT SET SCR X 3/4	4
19	8036600	1/4 STD LOCK WASHER	4
20	8034000	3/8-16 SKT HD CAP SCR X 1 1/4	2
21	8005600	3/8-16 SKT HD CAP SCR X 2 1/4	2
22	8024100	10-32 HEX HD NUT	2
23	8035700	1/4 SAE FLT WASHER	4
24	0038201	SHAFT MOUNT	2
25	8005400	3/8-16 SCKT FLAT HD X 1	2
26	8010000	3/8-16 HEX HD CAP SCR X 1	2
27	0200301	BUSHING	4



Bliss Box Former



Option Parts & Illustrations